

How to use your One Button Radio





+44 (0) 1780 489100

info@ravencourt.com

www.ravencourtliving.com

Registered in England. Company No. 1829882

Copyright © 2019 Designability.

Version 2.0 - Instructions for use_One Button Radio

Contents

About the One Button Radio	1
Product features	2
Setting up the One Button Radio	3
Using the One Button Radio	8
Playing your own music files on the One Button Radio	9
Technical and Safety Information	10
Help using your One Button Radio	11



About the One Button Radio

The One Button Radio is an easy-to-use AM/FM analogue radio, which has been designed for people with memory problems, and is also easy to use for people with reduced dexterity or visual impairment.

The One Button Radio can be set to a single radio station and a comfortable volume level, the control knobs are then removed and all other controls covered, so that the user can simply switch the radio on and off using the button on the top.



Product features



Setting up the One Button Radio

1

To use **batteries**, open the battery compartment on the back of the radio and insert **six** “C” or “LR14” batteries (not included), making sure the batteries are the right way round.



OR

To use **mains power**, open the storage compartment on the back of the radio, which contains:


- Mains power cable
- Volume knob
- Tuning knob



Plug the mains plug into a mains socket, and plug the other end of the cable into the power socket on the back of the radio (see page 2).



- 2 Remove the control knobs from the storage compartment and turn the radio to face you.



- 3 Take off the removable front panel (which is held on with magnets), using your thumbs or fingers to ease the top edge away from the radio as shown.



- 4 Push the volume knob and the tuning knob onto the front of the radio (each knob only fits one dial).

Volume knob (left)




Tuning knob (right)



- 5 Press the On/Off button on the top of the radio so that it is in the “on” position.


Note: You will not hear anything if the volume knob is not also rotated to the “on” position.



ON



OFF



6

Turn the radio on and set the volume level by rotating the volume knob clockwise.

Note: You should feel the knob ‘click’ into the “on” position and hear the radio as you increase the volume.



7

Programme the radio to your preferred station by rotating the tuning knob.

Note: Press the black AM/FM button next to the tuning knob to switch between AM and FM frequencies.

AM/FM button



- 8 Remove the volume and tuning knobs and store them in the back of the radio.



- 9 Hold the removable cover panel against the front of the radio and gently push it into place.



The radio is now ready to use.

Using the One Button Radio

Simply press the On/Off button on top of the radio to switch it on and off, and listen to your favourite radio station.



To change the station or adjust the volume, please refer to '**Setting up the One Button Radio**' on pages 4-6 (steps 2 to 7).


Playing your own music files on the One Button Radio

You can play your own music on the One Button Radio by putting audio files (mp3 format) on a USB stick and inserting it into the USB socket on the front of the radio.

The audio files will play automatically.

To switch back to listening to the radio, simply remove the USB stick from its socket.

Note: You may not be able to fit the removable cover panel on the front of the radio while the USB stick is in place.



Technical and Safety Information

- Quick and easy to set-up
- Can be operated with one button once set-up
- Magnetic front panel to cover controls
- Retro wood effect design
- AM/FM frequency radio stations
- Plays audio files from a USB stick (front cover must be removed)
- Mains or battery powered
- Batteries: 6 x LR14/Size C 1.5V (not included)
- Dimensions: 300 wide x 190 high x 150 deep
- AC/DC Adapter input: 230V~50Hz
- Cable length: 1.85 metres

WARNING

To reduce the risk of a fire or an electric shock, do not expose this radio to rain or moisture.



Help using your One Button Radio

If you have a question about your One Button Radio, need any help getting started, or if you require a large print version of these instructions, please get in touch:

Telephone number: **+44 (0) 1780 489100**

Email address: **info@ravencourt.com**

To download a copy of these instructions visit our website:

www.ravencourtliving.com



Registered in England. Company No. 1829882

Unique Collaboration

Ravencourt Living, Designability and Alzheimer's Society have come together in partnership, to offer a range of products to help people to live well with memory problems.

Designability are a UK charity who create life changing products for people living with disabilities. They designed the original Day Clock, Simple Music Player and One Button Radio.

Alzheimer's Society is the UK's leading dementia charity. They campaign for change, fund research to find a cure and support people living with dementia today.

Ravencourt have a reputation for producing quality products that make a real difference to people's lives.



designability.org.uk

Designability is a registered charity in England and Wales (256335). Designability is registered with the Fundraising Regulator.



Alzheimer's Society is a registered charity in England and Wales (296645) and the Isle of Man (1128). Alzheimer's Society is registered with the Fundraising Regulator.



+44 (0) 1780 489100

info@ravencourt.com

www.ravencourtliving.com