

## MPPL-ERTX Call pendant transmitter button

The MPPLERTX is a lightweight call pendant transmitter supplied with a wrist strap and lanyard attachment. The transmitter features a central easy press button with an LED which lights to confirm activation.

### General information

- Transmission range is approximately 30 to 70m depending on building construction or terrain (if used outdoors).
- Battery life can vary depending on the number of operations per day, typically six months can be expected

If you purchased the transmitter as part of a kit with a pager or other alarm receiver device you do not need to follow the pairing instructions, it is already factory set and ready to use.

If you are adding a second transmitter to a pager already purchased follow the pairing instructions for the pager.

### Replacing the battery

Remove the two small screws on the back of the case, being careful not to damage or lose them. Gently prise apart the two halves of the case. Replace the A27 12 Volt battery with a fresh one then replace the cover, re-insert the screws and gently tighten them. The transmitter should still be paired with the pager. Test it before use and re-pair if necessary.

### Pager not responding

- Press the transmitter button - does the red LED come on? If not check battery.
- Button LED lights but pager not responding. Check pager is switched on then press transmitter button.
- Pager still not responding. Try repairing the transmitter to the pager.
- Pager responds when transmitter button is close to it but not where I want it to. Is the transmitter too far away from the pager. Try moving closer. See warnings on pager instructions.

