

DAYCLOX 8E & 8000EC - USER INSTRUCTIONS



Congratulations, you have one of the Easy to Read" **8" Digital Calendar Day Clock**. Special Features include: With "Easy to Set-Up and change display.

If your Clock has a protective anti-scratch plastic cover on the screen, please carefully peel it off and remove it.

Press the Menu button on the back of the clock for the menu display: Please Note only the Highlighted Line within the Arrow Brackets < > can be adjusted:

Line 1, Set Time

Press the Left/Right buttons above the menu button a small blue bar to appear below the text line to be changed:

< **08 : 32** > then press the **UP / DOWN** button to adjust to the desired setting. Then with the Left/Right button move to the next < **08 : 32** > use the **UP / DOWN** buttons to adjust.



Please Note: When Changing or Setting the Time: The clock should be in the 24hr mode to identify the correct time of day. e.g. **3:00 p.m. = 15:00 hrs** When finished Press **OK** or **Menu** button to close.

Line 2, Set Date: - Press Menu button and then the **UP / DOWN** button to go to the next line to change. Press **Left/Right** buttons to highlighted a with the Blue bar the text to be adjusted: Change the day < **30** - 04 - 2017 > use **UP / DOWN** button to adjust the highlighted text. Change the month and year in the same way using the Left/Right buttons to highlight with the blue bar.

Line 3, Time Mode: Press Menu button and then the **UP / DOWN** button to go to the line to change. - Press the centre **OK** button to select either - **12hr or 24hr** (Press Menu to finish)

Line 4, Date Mode: Press the centre **OK** button to select either mode: (British Style) **DD/MM/YYYY** or (American Style) **MM/DD/YYYY** (Press Menu to finish)

Line 5, Display: (8000EC Model Only - Hidden below Line 4) Press Menu button and then the **UP / DOWN** button to go to the line to change. Press the OK button to Select preferred Mode: **Colour / Black & White**

DayClox Ltd. 145/155, High Street, RHYL. LL18 1UF - UK
email: sales@dayclox.com - Telephone: 01745 334020

DayClox - 07072017

DAYCLOX 8E & 8000EC - USER INSTRUCTIONS



Congratulations, you have one of the Easy to Read" **8" Digital Calendar Day Clock**. Special Features include: With "Easy to Set-Up and change display.

If your Clock has a protective anti-scratch plastic cover on the screen, please carefully peel it off and remove it.

Press the Menu button on the back of the clock for the menu display: Please Note only the Highlighted Line within the Arrow Brackets < > can be adjusted:

Line 1, Set Time

Press the Left/Right buttons above the menu button a small blue bar to appear below the text line to be changed:

< **08 : 32** > then press the **UP / DOWN** button to adjust to the desired setting. Then with the Left/Right button move to the next < **08 : 32** > use the **UP / DOWN** buttons to adjust.



Please Note: When Changing or Setting the Time: The clock should be in the 24hr mode to identify the correct time of day. e.g. **3:00 p.m. = 15:00 hrs** When finished Press **OK** or **Menu** button to close.

Line 2, Set Date: - Press Menu button and then the **UP / DOWN** button to go to the next line to change. Press **Left/Right** buttons to highlighted a with the Blue bar the text to be adjusted: Change the day < **30** - 04 - 2017 > use **UP / DOWN** button to adjust the highlighted text. Change the month and year in the same way using the Left/Right buttons to highlight with the blue bar.

Line 3, Time Mode: Press Menu button and then the **UP / DOWN** button to go to the line to change. - Press the centre **OK** button to select either - **12hr or 24hr** (Press Menu to finish)

Line 4, Date Mode: Press the centre **OK** button to select either mode: (British Style) **DD/MM/YYYY** or (American Style) **MM/DD/YYYY** (Press Menu to finish)

Line 5, Display: (8000EC Model Only - Hidden below Line 4) Press Menu button and then the **UP / DOWN** button to go to the line to change. Press the OK button to Select preferred Mode: **Colour / Black & White**

DayClox Ltd. 145/155, High Street, RHYL. LL18 1UF - UK
email: sales@dayclox.com - Telephone: 01745 334020

DayClox - 07072017