


transformer HD

How to install the Transformer HD software on your Android Tablet (rev 02.14.17)

1. Visit the Google Play App Store  on Android tablet.
2. Search “Enhanced Vision Transformer HD” You should see the icon below:
3. Click “Install” and “Accept” – Download will start
– Walk away at this point.
4. Launch the application on your Android device.
5. When prompted to install voice packs, follow the instructions on the screen.



How to make the Transformer Image appear on your Android Tablet via Wifi (rev 02.14.17)

1. Note the serial number of your Transformer HD.
2. Push the Green button once on the Transformer then walk away. You will hear some clicks and the lights will turn on. If the light is flashing, that means it is waiting for a signal.
3. Go to your “Settings” on your Android tablet. Click Wi-Fi – Find the Transformer HD serial number – Select it.
4. If asked to enter a password, you must enter EV_TransformerHD then click “join.” Please note this is case sensitive.
5. Make sure that the Transformer HD and the serial number you wish to use it with is check marked.
6. Then tap the Home button on the Android tablet.
7. Click on the Transformer App and walk away. Be patient as the Transformer turns on. You may temporarily see the Android tablet camera image appear on the screen. Do not worry – this is normal.



You are now ready to use the Transformer HD!

How To Make Sure Your Transformer is Fully Off on your Android Tablet

1. To fully shut down the Transformer HD, disconnect it from power and press and hold the green power button for 5 seconds.
2. To close the application on your Android tablet, simply tap the left hand icon button (two overlapping squares) next to the home button and close by pressing the “X.”

Samsung Android Tablets that work with Transformer HD as of Feb 2017

<u>Model</u>	<u>Transformer HD Compatible?</u>
Galaxy Tab / Galaxy Tab 7.0 – 2010	No
Galaxy Tab 7.0 Plus – 2011	No
Galaxy Tab 7.7 – 2011	No
Galaxy Tab 8.9 – 2011	No
Galaxy Tab 10.1 – 2011	No
Samsung Galaxy Tab 2 – 2012	Not Tested Yet
Samsung Galaxy Tab 3 – 2013	Not Tested Yet
Samsung Galaxy Tab 3 Lite – 2014	Not Tested Yet
Samsung Galaxy Tab 4 – 2014	Not Tested Yet
Samsung Galaxy Tab Pro – 2014	Not Tested Yet
Samsung Galaxy Tab S – 2014	Not Tested Yet
Samsung Galaxy Tab A – 2015	No
Samsung Galaxy Tab E – 2015	Not Tested Yet
Samsung Galaxy Tab S2 – 2015	Yes
Samsung Galaxy TabPro S - 2016	Not Tested Yet
Samsung Galaxy Tab A 10.1 – 2016	Not Tested Yet

Recommended Requirements for Android Tablets (rev 02.14.17)

Operating system	Android 4.4 or higher
Processor (CPU):	Exynos 7 Octa 5433 Octa-core, 1900 MHz, ARM Cortex-A57 and ARM Cortex-A53, 64-bit or higher
GPU	Mali-T760 MP6 or higher
RAM:	3 GB RAM or higher
Storage:	Total Storage of at least 16GB
Sample device meeting this requirements	Samsung Tab S2 http://www.samsung.com/us/explore/tab-s2-features-and-specs/

Recommended Requirements for MediaTek Processor Android Tablets (rev 02.14.17)

Operating system	Android 4.4 or higher
Processor (CPU):	MediaTek MT8732 Quad-core, 1500 MHz, ARM Cortex-A53, 64-bit
GPU	Mali-T760 MP2
RAM:	2 GB RAM or higher
Storage:	Total Storage of 16GB or higher
WiFi Network Adaptor:	802.11n 2.4 GHz wireless adaptor
Sample device meeting this requirements	Lenovo Tab 2 http://shop.lenovo.com/us/en/tablets/lenovo/a-series/tab2a10/