

BD_SW_2B_02 2 button dash mode switches for Ducati 848, 1098, 1198, Desmosedici

This switch is intended to replace the standard left hand handlebar switches on Ducati 848/1098/1198/Desmosedici track bikes which no longer require the light and turn signal controls, yet still require the use of the dash MODE functions.

The aluminium assembly has been designed ultra-slim and encompasses 2 green momentary switches.

No modification of the bike wiring is necessary, this kit plugs directly into the 8 way connector of the standard loom.




**Mating right side switch assembly
BD-SW-2B_01**



Function:

1	Green	Mode – UP	Momentary
2	Green	Mode - DOWN	Momentary



Electrical / Mechanical Characteristics

Wire..... Type 55 / 24
 Switch sealing..... IP67
 Housing..... Aluminium
 Coating..... Black anodise
 Dia (handlebar)22mm (7/8")

Max width 20.5 mm
 Min width at centre 13.5 mm
 Weight 85 g
Note – Do not press both buttons at the same time

Ordering Information

Part No.	Connector	Cable	Description
BD-SW-2B-02	'Plug n play'	380mm	2 way handlebar switch for Ducati MODE – 848/1098/1198/Desmosedici