


LED Motion Sensor Rechargeable Ceiling Light (EN)

PRODUCT FUNCTION



Power Indicator Light: Red light: Charging
Green light: Fully charged
Blue light: Low battery

Mode: Click to switch between the three mode of "Night-STEADY-DAY"

Mode Toggle:


- ☾ Night sensing mode
- ☀ Day sensing mode
- ☾ Always-on mode

Light: Click to switch between three color temperature
Long press to adjust the brightness

Power on/Power off

(The ceiling light will only work when the switch is set to the "on" position)

REMOTE CONTROL



Always-on mode



Daytime sensing mode



Night sensing mode



Turn off

Light



increase brightness



reduce brightness



Warm light



Natural light



Cold white light

Timing



15Min



30Min



60Min



120Min


15/30/60/120min



close timer

INSTALLTION

Drill-Free Installation



Accessories

Mounting patch

