



## Parts

1 x Lockable 4" Lid

2x Lockable Catch

4x Self Tapping Screws

## Tools

Phillips Head Electric / Manual Screw Driver

Marker

## Instructions

- Remove previous 4" Cap
- Clean and dry area around the 4" neck
- Place new lid into position
- Place the two catches on the "wings" of the lid
- Mark the outline of the catches on the tank
- Twist list away from catches, if the catches are disturbed, re-align them using the marked position
- Fasten the catches into position using the self-tapping screws
- Replace the 4 screws from the previous lid back into their holes to prevent water ingress
- Twist the lid back into the locked position