

# **VTKeys 2 Large Character USB Keyboard**

Please retain these instructions for future reference.

## **Special warning**

**Please note:** Must be used with Microsoft Windows.

## **General description**

This high quality, large print QWERTY keyboard has a detachable light to help reduce eye strain. The key mechanism enables light touch and quiet key operation.

## **Items supplied**

- USB keyboard – USB cable pre-connected
- Detachable LED down-light

## **Orientation**

Remove packaging and place the keyboard in front of you with the cable coming out of the back. On each end of this keyboard, towards the back is a USB socket.

A row of number keys and function keys run along the top. A number pad is located on the right hand side. 4 feature buttons are located on the top right. Starting at the top right working inwards, the buttons are:

- My computer
- Volume mute
- Increase volume
- Decrease volume

The light has a right angled USB connector at the base of the stem. At the opposite end is the light with a touch sensitive on/off button located on the tip.

## **Connecting the Keyboard to the Computer**

Connect the keyboard's USB cable to your computer. The cable is already connected to the back of the keyboard; find a suitable USB socket on your computer and insert the USB connector. Don't force the USB as this could damage the connection.

## **Using the detachable LED down-light**

The keyboard includes a flexible LED strip light which connects into one of the integrated side USB ports. This illuminates the keys, improving the contrast further. The brightness can be adjusted.

Connect the USB connector of the light into one of the USB sockets on the keyboard. Once connected, bend the light into your preferred position over the keys by bending and rotating the stem. To turn on, gently tap the end of the light once. Tap accordingly for the following functions:

- First tap, full brightness
- Second tap, lower brightness
- Third tap, turns off

## **Terms and conditions of sale**

This product is guaranteed from manufacturing faults for 24 months from the date of purchase.